

iGo8 sys.txt Med forklaring

Bidrag fra Administrator
Thursday 14. December 2006
Sist oppdatert Wednesday 25. July 2012

Oversikt over instillinger i sys.txt /system.ini med forklaringer.

[2d]

guidancearrow_disappearlevel=600

guidancearrow_maxshift=12

minguidancearrowsize=20

minguidancearrowsize_zoomlevel=1200

maxguidancearrowsize=65

maxguidancearrowsize_zoomlevel=0

[3d]

3d_tmc_road_extra_width=200

building_camera_distance_far=500

building_camera_distance_medium=50

building_camera_distance_near=10

disable_3d_labels=0

fade_distance_for_car=50

fade_distance_for_guidance_arrow=500

guidancearrow_contour

guidancearrow_first_size=1.1 ; Størrelse på første pil

guidancearrow_first_alpha=24 ; Gjennomsiktighet på første pil

guidancearrow_second_size=0.8

guidancearrow_second_alpha=12

guidancearrow_skew ;

guidancearrow_thickness ;

guidancearrow_width ;

guidancearrow_zoomfactor ;

max_poly_distance_lower

max_poly_distance_upper
max_poly_segments_shown
max_track_distance_lower
max_track_distance_upper
max_track_segments_shown
min_poly_distance
min_poly_segments_shown
min_track_distance
min_track_screen_ratio
min_track_segments_shown
road_clip_plane_camera_delta=50 ;
road_clip_plane_to_camera_height= ;
show_guidance_strip=1
show_guidance_arrows=1
track_screen_ratio
use_all_building_textures=0 ; not?

[3d_config]

disable_roadsign_navigation_mode=1
roadsign_lines_per_screen=12
rotated_roadsigns=1

[bluetooth]

send_showphoneui_on_dial=1

[config]

autoset2donmap=1
autoset3doncockpit=1

hideroadaltname=1

overspeedrewarnbelow=1

SafeModeMinSpeed=40

[debug]

autosave=1

bringtotop_afterresume=1

buildneworderlist=1

cache=2048

compass_type=2

disable_3d=0 ;disables 3d buildings and roads

disable_outlookpoi=1

double_pixel_mode=2 ;3d mode fastdraw

doublepixel_stable_frame_time=500 ;tid i millisekunder før du forlater hurtigfil

earth=1

enable_buildings=1

enable_landmark_occlusion=1

enable_roadshadow=1

enable_roadsign=1

fov=40

gnome_dem_files=1

hide_itiner_crossing=1

join_dual=0

lang_registry_2006=1loop_sim=1

loop_sim=1

max_memory=

mute_os_key=1 ; 1 slår av klikkelyden fra WinCE når du trykker på skjemen

no_file_cache="0"

nortc=1 ; RTC = real time clock aka enhetens interne klokke

pin_sets_start=1

poi_labels=1

replay_tmc=1

reserve_memory

run_on_mio_mantas=1

screen_calibration=1

show_arrows_on_route=1 ; små piler som viser rutens retning ved navigering

show_device_type=0

show_gps_pos=1 ; viser GPS-posisjon

show_lane_info=1

show_ltn=1

show_multinode_maneuvers=1

show_oneway_3d=1 ; 3d-piler i enveiskjøringer

show_oneway=1 ; vis enveiskjøringer (av/på)

show_pedestrian=1

show_performance=0 ; cpu / mem / viser verdier øverst i skjermen

show_plural=1

show_poi_areas=1

show_poi_boundingrects=1

show_priority_maneuvers=1

show_prohibited_maneuvers=0

show_rawdisplay_info=0 ; viser hvilken display-driver som er i bruk

show_residentonly=0

show_speed_limit=1

show_turn_penalty=1

show_signpost=1

sim_speed_factor_max=8.0

skip_eula=1 ;hopper over End User License Agreement ved oppstart (vises kun ved første oppstart uansett)

slowsim=1

smart_2d=1

sound_q_length=200

speedcam_enabled=1

split_dual=0

strap_waypoints=1

supress_highway_enter=0

supress_straight=0

supress_trivial_left=0

supress_trivial_right=0

tmc_all_stations=1 topmost=1

traincrossing=1

tts_expected_engine_delay=1400

tts_getaway_time=200

tts_min_ready_wav=1

[defaults]

mainroadness=60

shortness=50

simplificationness=40

[device]

type="MIOC210" ; henter spesifikt oppsett for denne enheten

typeid=3 ;In lgo8.exe: MIO enhet oppdaget, bruk KernelIOControl metode

[feature]

text_guidance=1

signpost_coloring=1

tmc_event_coloring=1

tmc_traffic_side=1

[folders]

app="%SDCARD%/iGO8" ; sti til applikasjonen

sdcardpath="\Storage Card"

exe=""

data="\Storage Card\igo" ;egen lagringsmappe

content="\Storage Card\igo\CONTENT"

textures="custom"

models="custom"

secondary_root="IPAQ\NAV"

[gps]

background_navigation=1

logging=0 ; se også mydata.tracks

port=2

baud=38400

source="nmea"

disable_advanced=0

default_longitude=2.294760 ;startposisjon på kartet før GPS-signaler er funnet.

default_latitude=2.294760 ;startposisjon på kartet før GPS-signaler er funnet.

[interface]

angleoffset=

autotilt=0

autotilt_minzoom3d=40

autotilt_maxzoom3d=1000

autoscroll_on_click=1

default_poi_icon="Contacts" ;

defaulttilt3d=75000

defaultzoom2d=1000

defaultzoom3d=500

disable_3dstick_labels=1 ;

drive_carefully=0

empty_favorites=1

exit_on_restart=0

laneinfo_signpost_enabled=1

mapfontscale=130 ; for 2d og 3d kart

maxzoom2d=60000 ; zoom-ut nivå (60000 viser jorda fra verdensrommet)

minzoom2D=40 ; zoom-inn nivå 2d

minzoomglobe=100000

msgbox_max_width=50

newalignment=1 ;

poi_show_all_btn=1

popup_info=1

resolution_dir="320_240" ; angir skjermstørrelse hvis du har mulighet for fler enn en (avhengig av malen)

screen_snap_distance=40

showselection=1

show_exit=1 ; vis exit-knapp

show_gps_config=1

show_minimize=1
; vis minimer-knapp

show_orientation=1

show_timezone_slider=1 ;

show_tmc_config=1

show_zoombar=1 ; se også zoomscale_disappearing

shutdown_time=0

skin="ui_igo8"

spec_fav_count=4

theme="skin\igo8_plus.zip"

use_big_lang_flag=1

use_spec_fav=1

waypoint_list_ignore_autosource=1

vga=1

Zoom2dpercent=

show_only_ahead_of_car=1

[kml]

default_icon=1

[loading]

loading_bmp="loading.jpg"

progressbar_bmp="loading_progressbar.bmp"

progressbar_x=85

progressbar_y=134

show_progressbar=0

show_statustext=1

supress_straight=0

supress_highway_enter=0

supress_trivial_left=0

supress_trivial_right=0

text_align=1 ;Venstre=0,Senter=1,Høyre=2 and Justify=3

text_fontcolor=xFFFFFFF

text_fontsize=30

text_w=600

text_x=100

text_y=400

traincrossing=1

[local]

; Datoformat: For å velge det formatet du vil ha, slett ;-tegnet foran den linjen du vil bruke

; Dateformat = 0; YYYY-MM-DD

; Dateformat = 1; AAAA.MM.GG

; Dateformat = 2; YYYY / MM / DD (DEFAULT)

; Dateformat = 3; YYYY-MM-DD

; Dateformat = 4; AAAA.GG.MM

; Dateformat = 5; YYYY / MM / DD

; Dateformat = 6; DD-MM-YYYY

; Dateformat = 7; DD.MM.YYYY

; Dateformat = 8; DD / MM / YYYY

; Dateformat = 9; MM-DD-YYYY

; Dateformat = 10; MM.GG.AAAA

; Dateformat = 11; MM / DD / YYYY

[map]

2dheadup=1

3d_brunnel_shutdown=

3d_buildings=1

3d_buildings_distance=2

3dcarsizemin=5000

3dcarsizemax=10000

3dcarsizemul=30000

3d_dem=1

3d_dem_detail=2

3d_landmarks=1

3d_max_tiltlevel=7500

3d_max_zfar=500

3d_max_zoomlevel=2000

3d_min_zoomlevel=40

3d_roads=1

3d_scale_carmodel=1

3d_tunnels=1

alternative_roadnames=0

auto_nightmode=0 ; 1 = skifter til nattmodus om kvelden (se også nightmode)

cross_border_routes=1

follow_gps=1

inertia_on_map_move=1 ; velger autoscroll på kartet, funksjonen kan være ustabil eller hakkete.

map_mode="3D"

maxFovRatioForPoly=8

maxPolyDistances0 = 2000

maxPolyDistances1 = 3000

maxPolyDistances2 = 4000

maxPolyDistances3 = 5000

maxTrackDistances0 = 2500

maxTrackDistances1 = 3500

maxTrackDistances2 = 4500

maxTrackDistances3 = 5500

minPolyDistances0 = 500

minPolyDistances1 = 500

minPolyDistances2 = 500

minPolyDistances3 = 500

minTrackDistances0 = 500

minTrackDistances1 = 500

minTrackDistances2 = 500

minTrackDistances3 = 500

roadblockicon_maxzoom=2000

rotation="0"

shields=1

show_labels=1 ;

show_oneway=1 ; skrur av eller på visning av enveiskjøringer

stop_rotate_on_map_move=1

terrain_in_2d=0

textured_poly=1

viewpreset_front1="30,100,7200,10"

viewpreset_front2="140,7000,6000,10"

viewpreset_front3="140,7000,6000,10"

viewpreset_top="600,50000,225,10"

zoomscale_disappearing=1 ; fungerer sammen med show_zoombar

English:

[2d]

guidancearrow_disappearlevel=600

guidancearrow_maxshift=12

minguidancearrowsize=20

minguidancearrowsize_zoomlevel=1200

maxguidancearrowsize=65

maxguidancearrowsize_zoomlevel=0

[3d]

3d_tmc_road_extra_width=200

building_camera_distance_far=500

building_camera_distance_medium=50

building_camera_distance_near=10

disable_3d_labels=0

fade_distance_for_car=50

fade_distance_for_guidance_arrow=500

guidancearrow_contour

guidancearrow_first_size=1.1 ; scale of 1st arrow

guidancearrow_first_alpha=24 ; transp of 1st arrow

guidancearrow_second_size=0.8

guidancearrow_second_alpha=12

guidancearrow_skew ;

guidancearrow_thickness ;
guidancearrow_width ;
guidancearrow_zoomfactor ;
max_poly_distance_lower
max_poly_distance_upper
max_poly_segments_shown
max_track_distance_lower
max_track_distance_upper
max_track_segments_shown
min_poly_distance
min_poly_segments_shown
min_track_distance
min_track_screen_ratio
min_track_segments_shown
road_clip_plane_camera_delta=50 ;
road_clip_plane_to_camera_height= ;
show_guidance_strip=1
show_guidance_arrows=1
track_screen_ratio
use_all_building_textures=0 ; not?

[3d_config]

disable_roadsign_navigation_mode=1
roadsign_lines_per_screen=12
rotated_roadsigns=1

[bluetooth]

send_showphoneui_on_dial=1

[config]

autoset2donmap=1

autoset3doncockpit=1

hideroadaltname=1

overspeedrewarnbelow=1

SafeModeMinSpeed=40

[debug]

autosave=1

bringtotop_afterresume=1

buildneworderlist=1

cache=2048

compass_type=2

disable_3d=0 ;disables 3d buildings and roads

disable_outlookpoi=1

double_pixel_mode=2 ;3d mode fastdraw

doublepixel_stable_frame_time=500 ;time in ms before leavin fastdraw

earth=1

enable_buildings=1

enable_landmark_occlusion=1

enable_roadshadow=1

enable_roadsign=1

fov=40

gnome_dem_files=1

hide_itiner_crossing=1

join_dual=0

lang_registry_2006=1loop_sim=1

loop_sim=1

max_memory=

mute_os_key=1 ; a value of 1 mutes the click noise from the OS when touching a touchscreen

no_file_cache="0"

nortc=1 ; RTC = real time clock aka the devices internal clock

pin_sets_start=1

poi_labels=1

replay_tmc=1

reserve_memory

run_on_mio_mantas=1

screen_calibration=1

show_arrows_on_route=1 ; little arrows in direction of route

show_device_type=0

show_gps_pos=1 ; this works again ;O)

show_lane_info=1

show_ltn=1

show_multinode_maneuvers=1

show_oneway_3d=1 ; 3d arrows in one way streets

show_oneway=1 ; show one way on or off

show_pedestrian=1

show_performance=0 ; cpu / mem / whatever bars on top of screen

show_plural=1

show_poi_areas=1

show_poi_boundingrects=1

show_priority_maneuvers=1

show_prohibited_maneuvers=0

show_rawdisplay_info=0 ; handy for seeing what igo chooses as display driver

show_residentonly=0

show_speed_limit=1

show_turn_penalty=1

show_signpost=1

sim_speed_factor_max=8.0

skip_eula=1 ;skips the End User License Agreement at start-up (only happens on first run anyways)

slowsim=1

smart_2d=1

sound_q_length=200

speedcam_enabled=1

split_dual=0

strap_waypoints=1

supress_highway_enter=0

supress_straight=0

supress_trivial_left=0

supress_trivial_right=0

tmc_all_stations=1 topmost=1

traincrossing=1

tts_expected_engine_delay=1400

tts_getaway_time=200

tts_min_ready_wav=1

[defaults]

mainroadness=60

shortessness=50

simplificationness=40

[device]

type="MIOC210" ; force device type

typeid=3 ;In lgo8.exe: MIO device detected, use KernelIOControl method

[feature]

text_guidance=1

signpost_coloring=1

tmc_event_coloring=1

tmc_traffic_side=1

[folders]

app="%SDCARD%/iGO8" ; change this if applicable

sdcardpath="\Storage Card"

exe=""

data="\Storage Card\igo" ;custom,save

content="\Storage Card\igo\CONTENT"

textures="custom"

models="custom"

secondary_root="IPAQ\NAV"

[gps]

background_navigation=1

logging=0 ; see also mydata.tracks

port=2

baud=38400

source="nmea"

disable_advanced=0

default_longitude=2.294760 ;starting postion on the map before GPS is found.

[interface]

angleoffset=

autotilt=0

autotilt_minzoom3d=40

autotilt_maxzoom3d=1000

autoscroll_on_click=1

default_poi_icon="Contacts" ;

defaulttilt3d=75000

defaultzoom2d=1000

defaultzoom3d=500

disable_3dstick_labels=1 ;

drive_carefully=0
empty_favorites=1
exit_on_restart=0
laneinfo_signpost_enabled=1
mapfontscale=130 ; for 2d and 3d map
maxzoom2d=60000 ; zoom out level (disabled get you into space ;O)
minzoom2D=40 ; zoom in level 2d
minzoomglobe=100000
msgbox_max_width=50
newalignment=1 ;
poi_show_all_btn=1
popup_info=1
resolution_dir="320_240" ; tells what resolution to use in a multires skin
screen_snap_distance=40
showselection=1
show_exit=1 ; obvious
show_gps_config=1
show_minimize=1
show_orientation=1
show_timezone_slider=1 ;
show_tmc_config=1
show_zoombar=1 ; also see zoomscale_disappearing
shutdown_time=0
skin="ui_igo8"
spec_fav_count=4
theme="skin\igo8_plus.zip"
use_big_lang_flag=1
use_spec_fav=1
waypoint_list_ignore_autosource=1
vga=1
Zoom2dpercent=

[itiner]

show_only_ahead_of_car=1

[kml]

default_icon=1

[loading]

loading_bmp="loading.jpg"

progressbar_bmp="loading_progressbar.bmp"

progressbar_x=85

progressbar_y=134

show_progressbar=0

show_statustext=1

supress_straight=0

supress_highway_enter=0

supress_trivial_left=0

supress_trivial_right=0

text_align=1 ;Left=0,Center=1,Right=2 and Justify=3

text_fontcolor=xFFFFFFF

text_fontsize=30

text_w=600

text_x=100

text_y=400

traincrossing=1

[local]

; Date Format: To select your desired format, delete the ; in front of the format you want and ; in front of the rest (or just

delete all of the other lines)

; Dateformat = 0; YYYY-MM-DD

; Dateformat = 1; AAAA.MM.GG

; Dateformat = 2; YYYY / MM / DD (DEFAULT)

; Dateformat = 3; YYYY-MM-DD

; Dateformat = 4; AAAA.GG.MM

; Dateformat = 5; YYYY / MM / DD

; Dateformat = 6; DD-MM-YYYY

; Dateformat = 7; DD.MM.YYYY

; Dateformat = 8; DD / MM / YYYY

; Dateformat = 9; MM-DD-YYYY

; Dateformat = 10; MM.GG.AAAA

; Dateformat = 11; MM / DD / YYYY

[map]

2dheadup=1

3d_brunnel_shutdown=

3d_buildings=1

3d_buildings_distance=2

3dcarsizemin=5000

3dcarsizemax=10000

3dcarsizemul=30000

3d_dem=1

3d_dem_detail=2

3d_landmarks=1

3d_max_tiltlevel=7500

3d_max_zfar=500

3d_max_zoomlevel=2000

3d_min_zoomlevel=40

3d_roads=1

3d_scale_carmodel=1

3d_tunnels=1

alternative_roadnames=0

auto_nightmode=0 ; see also nightmode

cross_border_routes=1

follow_gps=1

inertia_on_map_move=1 ; sets autoscroll on the map, tends to be buggy though sometimes doesn't stop.

map_mode="3D"

maxFovRatioForPoly=8

maxPolyDistances0 = 2000

maxPolyDistances1 = 3000

maxPolyDistances2 = 4000

maxPolyDistances3 = 5000

maxTrackDistances0 = 2500

maxTrackDistances1 = 3500

maxTrackDistances2 = 4500

maxTrackDistances3 = 5500

minPolyDistances0 = 500

minPolyDistances1 = 500

minPolyDistances2 = 500

minPolyDistances3 = 500

minTrackDistances0 = 500

minTrackDistances1 = 500

minTrackDistances2 = 500

minTrackDistances3 = 500

roadblockicon_maxzoom=2000

rotation="0"

shields=1

show_labels=1 ;

show_oneway=1 ; turns on or off the arrows showing one way streets

stop_rotate_on_map_move=1

terrain_in_2d=0

textured_poly=1

viewpreset_front1="30,100,7200,10"

viewpreset_front2="140,7000,6000,10"

viewpreset_front3="140,7000,6000,10"

viewpreset_top="600,50000,225,10"

zoomscale_disappearing=1 ;

works with show_zoombar